

GUARDIAN[®]

merchandiser



ZERO ZONE
GUARDIAN[®] MERCHANDISER
CGLC & CGMC
With CoolView[®] Doors
INSTALLATION & OPERATION MANUAL



66-0169 REV B • MAY 2026



Table of Contents

ZERO ZONE WARRANTY	1
INTRODUCTION	2
■ Competence of Service Personnel	3
■ Safety	5
■ Symbols and definitions	5
PLANNING	6
■ Permitting	6
■ Entrance & Unloading	6
■ Case Installation & Mobilization	6
■ Heat Rejection	6
■ Electrical	6
INSTALLATION & OPERATION	7
■ Delivery Inspection	7
■ Packaging	7
■ Location	7
■ Moving Cases	8
■ Leveling	8
■ Lineup Assembly	10
■ Case Joint Caulking (Butyl*)	12
■ NSF Compliance Sealing (Silicone)	13
■ Packaged Refrigeration Unit (PRU) Installation	14
■ Controller Installation	15
■ Shroud Installation	15
■ Roll Guard	16
■ CoolView® Doors	16
■ Door Handles	16
■ Hold-Open Bracket	16
■ Door Gasket	16
■ Packaged Refrigeration Unit (PRU) Removal	17
■ Adjusting Door Sag/Sawtooth	18
■ Torque Adjuster / Adjusting Door Tension	18
■ Removing a Door	18
■ Installing a Door	19
■ Reversing Door Swing	19
■ Light Replacement	20
■ Shelves & Stocking Product	21
REFRIGERATION	22
■ Air Sensors & Case Thermometers	22
■ Anti-Sweat Heaters	23
■ Wiring Information	23
■ Electrical Power Distribution Assembly Wiring	23
■ Terminal Block Connections	24
■ Wiring Labels	24
■ Other Information	24
MAINTENANCE	25
■ Cleaning	25
■ Under Case Floor Cleaning (NSF)	25
APPENDIX	26
■ Removal and Replacement of the Evaporator Cover	26
■ Evaporator Cover Removal	26
■ Evaporator Cover Installation	26

ZERO ZONE WARRANTY

Limited Warranty

Zero Zone, Inc. (Seller) hereby warrants that any products sold are warranted to be free from defects in material and workmanship, under normal use and service for its intended purpose, for a period of three (3) years from the date of original installation (not to exceed 39 months from the date of factory shipment). Zero Zone ChillBrite® LED Lighting carries a 5-year parts warranty. Zero Zone CoolView® Doors carry a 10-year glass pack parts warranty. The obligation under this warranty shall be limited to repairing or exchanging any part, or parts, FOB Factory, which is proven to the satisfaction of the Zero Zone Service Department to be defective. Zero Zone reserves the right to inspect the job site, installation, and reason for failure. This limited warranty does not cover freight, or loss of food or product, including refrigerant loss. Any products sold on an "AS IS" basis shall not be covered by this warranty.

WARRANTY CLAIMS

All claims for labor and parts must be handled directly with Zero Zone.

- Customers are required to contact Zero Zone's Customer Experience Team to coordinate and schedule all warranty repairs. Case model and serial number will be required to schedule any service visits.
- All claims will require case model and serial number and the Package Refrigeration Unit (PRU) model and serial number if applicable.
- If the equipment has surpassed the 36 months from shipment, but not exceeded 39 months from shipment, customer will require proof of installation date.
- Retailer and/or the Refrigeration Contractor must contact Zero Zone's Technical Services Department to assist and confirm the diagnosis PRIOR to any work being started.
- All information related to the component, or system failure will need to be documented and presented to Zero Zone Technical Services Team.
- Claims can be mailed to service.cases@zero-zone.com with model and serial numbers, photos and documentation of the problem(s) including a Zero Zone Work Order #.
- Failure to notify Zero Zone prior to repairing equipment will breach this warranty and will hold it null and void.
- Zero Zone reserves the right to require any failed part covered under warranty to be returned.

WHAT IS NOT COVERED UNDER THIS WARRANTY

Zero Zone's obligation under this warranty is limited to either the repair or replacement of parts, at Zero Zone's discretion. This warranty neither assumes, nor authorizes, any person to assume obligations other than those expressly covered by this warranty.

- **NO CONSEQUENTIAL DAMAGES:** Zero Zone is not responsible for economic loss; profit loss; or special, indirect or consequential damages, including without limitation, loss or damage arising from loss of product, whether or not on account of failure of the refrigeration system.
- **WARRANTY IS NOT TRANSFERABLE:** This warranty is not assignable and applies only in favor of the original purchaser/user and the original installation location. ANY SUCH ASSIGNMENT OR TRANSFER SHALL VOID ALL WARRANTIES, EXPRESS OR IMPLIED.
- **IMPROPER USAGE/INSTALLATION:** Zero Zone assumes no liability for parts or labor coverage for component failure or other damages resulting from improper usage, negligence or installation error. This includes lack of preventative and/or regular maintenance as defined in the Zero Zone Installation & Operational Manual located at www.zero-zone.com.
- **RELOCATION FOR REPAIR:** Zero Zone is not responsible for the cost to move the equipment, or any other fixture or piece of equipment, for any reason from its position of operation on the user's premises to make a warranty repair.
- **NON-OEM PARTS:** OEM parts will be provided under this warranty free of charge to the end-user. Zero Zone is not responsible for defects or damage caused by parts not approved by Zero Zone. Warranty will be voided for any damage caused by a non-OEM part.
- **ALTERATION, NEGLECT, ABUSE, MISUSE, ACCIDENT, DAMAGE DURING TRANSIT OR INSTALLATION, FIRE, FLOOD, ACTS OF GOD:** Zero Zone is not responsible for the repair or replacement of any parts that Zero Zone determines have been subjected after the date of manufacture to alteration, neglect, abuse, misuse, accident, or damage during transit or installation, fire, flood, or act of God.

ZERO ZONE WARRANTY

- **IMPROPER ELECTRICAL CONNECTIONS FOR ANY REASON:** Zero Zone is not responsible for the repair or replacement of failed or damaged components resulting from incorrect supply voltage, the use of extension cords, low voltage, or unstable supply voltage.
- **NO IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE: THERE ARE NO OTHER WARRANTIES, EXPRESSED, IMPLIED OR STATUTORY, EXCEPT AS SET FORTH IN THIS WARRANTY STATEMENT. THESE WARRANTIES ARE EXCLUSIVE AND IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING IMPLIED WARRANTY AND MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. THERE ARE NO WARRANTIES WHICH EXTEND BEYOND THE DESCRIPTION ON THE FACE HEREOF.**

INTRODUCTION

Important User Information

Copyright © 2025 Zero Zone, Inc.

All rights reserved. No part of the contents of this manual may be reproduced, copied, or transmitted in any form or by any means including graphic, electronic, or mechanical methods or photocopying, recording, or information storage and retrieval systems without the written permission of the publisher, Zero Zone, unless it is for the purchaser's personal use.

The information in this manual is subject to change without notice and does not represent a commitment on the part of Zero Zone. Zero Zone does not assume any responsibility for any errors that may appear in this manual. In no event will Zero Zone be liable for technical or editorial omissions made herein, nor for direct, indirect, special, incidental, or consequential damages resulting from the use or defect of this manual.

The information in this document is not intended to cover all possible conditions and situations that might occur. The end user must exercise caution and common sense when installing, using, or maintaining Zero Zone products. Zero Zone products should only be installed by qualified, professional refrigeration technicians. If any questions or problems arise, call Zero Zone at 800-247-4496.

Any change to a Zero Zone product made during the installation, start-up, or at any other time must be submitted in writing to Zero Zone for approval and be approved by Zero Zone in writing prior to commission. The product warranty is voided when any unapproved change is made to a Zero Zone product.

Manufacturer

Zero Zone, Inc.

110 N Oakridge Dr • North Prairie, WI 53153 • 800-247-4496 • www.zero-zone.com

Intended Use

Zero Zone products are intended to be installed and used as described in this manual and other related Zero Zone literature, specifications, drawings, and data. All Zero Zone products must be leveled after being installed.

This appliance is not intended for use by persons (including children) with reduced physical, sensory, or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety. Children should be supervised to ensure that they do not play with the appliance.

Do not store explosive substances such as aerosol cans with a flammable propellant in this appliance.

Testing Standards

These display cases were designed and tested using the following industry standards:

- NSF 7 – Commercial Refrigerators and Freezers (ANSI Approved) (equipment certified by NSF)
- NSF 51 – Food Equipment Materials (ANSI Approved) (equipment certified by NSF)
- UL 60335-2-89 – Commercial Refrigerating Appliances and Ice-Makers with an Incorporated or Remote Refrigerant Unit or Motor-Compressor (ANSI Approved) (equipment certified by ETL)
- ASHRAE Standard 72 – Method of Testing Commercial Refrigerators and Freezers (ANSI Approved)
- AHRI 1200 – Performance Rating of Commercial Refrigerated Display Merchandisers and Storage Cabinets (ANSI Approved)
- DOE Compliant (All U.S. Sales and U.S. Territories)
- NRCan Certified
- Energy Star Certified

INTRODUCTION

ASHRAE Standard 72 specifies the test conditions for the equipment. It includes the ambient conditions of 75°F dry bulb and 55% RH. It also specifies the door opening requirements for the performance test. Doors are opened 6 times in 1 hour for 6 seconds. The door opening test period is for 8 hours during a single 24-hour performance test. As an example, a 5-door case will have 240 door openings during one 24-hour test. Consult the factory if your store exceeds these test conditions.

Display Case Models

The information contained in this manual pertains to the following Zero Zone display cases:

CASE MODEL	DESCRIPTION	DOOR SIZE & TYPE
CGMC30	Standard Cooler	30" x 68" CoolView® Envision® Doors
CGLC30	Standard Freezer	30" x 68" CoolView® Envision® Doors

Case Features

Zero Zone produces high quality refrigerated display cases using state-of-the-art components. The cases are built with the thickest insulation in the industry and a high efficiency evaporator coil. Case features include:

- Brushless DC electronic motors
- Zero Zone ChillBrite® LED Lighting
- Zero Zone CoolView® Envision® Doors
- R-290 Propane Refrigerant Roof-Mounted Packaged Refrigeration Unit (PRU)—Refer to the PRU manual for more information.

Competence of Service Personnel

Service must only be performed by a qualified professional and as recommended by the manufacturer. Work shall be undertaken under a controlled procedure to minimize the risk of a flammable gas or vapor being present while the work is being performed.

Service technicians should be trained by a national training organization or by manufacturers that are accredited to teach the relevant national competency standards. The achieved competence should be documented by a certificate.

Training should include the following:

- Information about the explosion potential of flammable refrigerants to show that flammables can be dangerous when handled without care.
- Information about potential ignition sources, especially those that are not obvious, such as lighters, light switches, vacuum cleaners, and electric heaters.
- Information about the different safety concepts:
 - **Unventilated** - Safety of the appliance does not depend on ventilation of the housing. Switching off the appliance or opening of the housing has no significant effect on the safety. Nevertheless, it is possible that leaking refrigerant may accumulate inside the enclosure and flammable atmosphere will be released when the enclosure is opened.
 - **Ventilated Enclosure** - Safety of the appliance depends on ventilation of the housing. Switching off the appliance or opening of the enclosure has a significant effect on the safety. Care should be taken to ensure sufficient ventilation before opening.
 - **Ventilated Room** - Safety of the appliance depends on the ventilation of the room. Switching off the appliance or opening of the housing has no significant effect on the safety. The ventilation of the room should not be switched off during repair procedures.

INTRODUCTION

- Information about refrigerant detectors:
 - Principle of function, including influences on the operation.
 - How to repair, check, or replace a refrigerant detector or parts of it in a safe way.
 - How to disable a refrigerant detector in case of repair work on the refrigerant carrying parts.
- Information about the concept of sealed components and sealed enclosures according to IEC 60079-15.

Training should include the following work procedures:

- Commissioning
 - Ensure that the floor area is sufficient for the refrigerant charge or that the ventilation duct is assembled in a correct manner.
 - Check safety equipment before putting into service.
- Maintenance / Repair
 - Portable equipment is to be repaired outside or in a workshop specially equipped for servicing units with flammable refrigerants.
 - Ensure sufficient ventilation at the repair place.
 - Be aware that malfunction of the equipment can be caused by refrigerant loss and a refrigerant leak is possible.
 - Discharge capacitors in a way that will not cause any sparks. The standard procedure to short circuit the capacitor terminals usually creates sparks.
 - When brazing is required, the following procedures shall be carried out in the following order:
 1. Safely remove the refrigerant following local and national regulations (See EPA Regulations 608). If the recovery is not required by national regulations, drain the refrigerant to the outside. Take care that the drained refrigerant will not cause any danger. If in doubt, one person should guard the outlet. Take special care that drained refrigerant will not float back into the building.
 2. Purge the refrigerant circuit with oxygen free nitrogen.
 3. Evacuate the refrigerant circuit.
 4. Purge the refrigerant circuit with nitrogen for 5 min.
 5. Evacuate again.
 6. Remove parts to be replaced by cutting or brazing.
 7. Purge the braze point with nitrogen during the brazing procedure required for repair.
 8. Carry out a leak test before charging with refrigerant.
 - Reassemble sealed enclosures accurately. If seals are worn, replace them.
 - Check safety equipment before putting into service.
- Decommissioning
 - If the safety is affected when the equipment is put out of service, the refrigerant charge must be removed before decommissioning.
 - Ensure sufficient ventilation at the equipment location.
 - Be aware that malfunction of the equipment can be caused by refrigerant loss and a refrigerant leak is possible.
 - Discharge capacitors in a way that will not cause any sparks. The standard procedure to short circuit the capacitor terminals usually creates sparks.
 - Safely remove the refrigerant following local and national regulations (See EPA Regulations 608). If the recovery is not required by national regulations, drain the refrigerant to the outside. Take care that the drained refrigerant will not cause any danger. If in doubt, one person should guard the outlet. Take special care that drained refrigerant will not float back into the building.
 - When flammable refrigerants are used:

INTRODUCTION

- 1. Evacuate the refrigerant circuit.
 - 2. Purge the refrigerant circuit with nitrogen for 5 min.
 - 3. Evacuate again.
 - 4. Fill with nitrogen up to atmospheric pressure.
 - 5. Put a label on the equipment that the refrigerant is removed.
- Disposal
- Ensure sufficient ventilation at the working place.
 - Safely remove the refrigerant following local and national regulations (See EPA Regulations 608). If the recovery is not required by national regulations, drain the refrigerant to the outside. Take care that the drained refrigerant will not cause any danger. If in doubt, one person should guard the outlet. Take special care that drained refrigerant will not float back into the building.
 - When flammable refrigerants are used,
 - 1. Evacuate the refrigerant circuit.
 - 2. Purge the refrigerant circuit with oxygen free nitrogen.
 - 3. Evacuate again.
 - 4. Cut out the compressor and drain the oil.
 - Cut out the compressor and drain the oil.

Safety

See the Packaged Refrigeration Unit (PRU) manufacturer's documentation for flammable refrigerant safety information.

 **WARNING!** KEEP CLEAR OF OBSTRUCTION ALL VENTILATION OPENINGS IN THE APPLIANCE ENCLOSURE OR IN THE STRUCTURE FOR BUILDING-IN.

 **WARNING!** DO NOT USE ELECTRICAL APPLIANCES INSIDE THE FOOD/ICE STORAGE COMPARTMENTS UNLESS THEY TYPE RECOMMENDED BY THE MANUFACTURER

SYMBOLS AND



DEFINITIONS

Symbol ISO 70000-1701 (2004-01)

Pressure



Symbol ISO 7010-W021

Flammable

PERMITTING

- Required case permits for Guardian® installation should be classified as “self-contained.”
- Always check with the local inspector to make sure your installation complies with local code requirements.
- Does your permitting require there to be seismic restraints?

ENTRANCE & UNLOADING

- What is the height of the entryway that the case(s) will need to go through? This should be addressed in the order stage.
- Where will the case(s) be unloaded from the truck? Is there room for the case(s) to be unloaded from the truck?

CASE INSTALLATION & MOBILIZATION

- Are you able to maneuver the case(s) throughout the store to final location?
- The refrigeration unit will produce some noise. Has this been taken into account when identifying the final location for these case(s)?
- Have you considered the door opening/swing and aisle width? (Not applicable to open cases.)

HEAT REJECTION

- Has the rejected heat from refrigeration unit(s) into store been considered?
- Do you have adequate room around the case(s) for the refrigeration unit to be able to reject heat? There should be a 30" minimum clearance between the top of shroud and the store ceiling.
 - Options/considerations if the clearance is less than the 30" minimum:
 - Add non-arcing auxiliary fans to dissipate heat.
 - Use louvered case shrouds.
 - Use an alternate shroud height (contact your Zero Zone Sales Representative).

ELECTRICAL

- Is there suitable power supply for necessary voltage and amperage?



CAUTION!

VERIFY THAT THE CORRECT SUPPLY VOLTAGE FROM BUILDING POWER IS PRESENT BEFORE ENERGIZING THE EQUIPMENT. THE LOW-TEMPERATURE DISPLAY CASE REQUIRES 208 VAC, AND THE MEDIUM TEMPERATURE DISPLAY CASE REQUIRES 115 VAC. VERIFY THAT ALL PHASES MEASURE 115 VAC AND ENSURE THAT NO PHASE IS CONNECTED TO THE HIGH LEG OF THE BUILDING'S ELECTRICAL SERVICE. MEASURE ALL LEGS TO NEUTRAL.

- Is the appropriate circuit breaker installed and available in the store power panel?
- Is the display case power receptical installed?

PLANNING

⚠ CAUTION! DO NOT STAND ON TOP OF A GUARDIAN® MERCHANDISER. THE TOP OF THE CASE IS NOT DESIGNED TO SUPPORT THE WEIGHT OF A PERSON.

Delivery Inspection


Zero Zone display cases are carefully factory-tested, inspected, and packed to ensure delivery in the best possible condition. The equipment should be unwrapped and checked for damage **immediately** upon delivery. **DAMAGE MUST BE NOTED AT TIME OF DELIVERY, AND ALL CLAIMS FOR DAMAGES MUST BE FILED WITH THE TRANSPORTATION COMPANY, NOT WITH ZERO ZONE.** The carrier will supply necessary report and claim forms. Contact your Zero Zone sales representative or the service department to arrange for replacement parts.

Do not leave, store, or hold case outdoors in direct sunlight or high ambient temperature. With the end panels on, the case is airtight; the inside temperature of the case will increase, and the heat will be unable to escape. This could potentially cause any plastic inside the case to deform or warp.

Packaging

Each **case** in a lineup is labeled to identify the **lineup** and **joint**. The label uses a 2-digit number designation, separated by a decimal. The first number indicates the case lineup. The second number indicates the case joint. Case joints begin with the number “1” at the left-most joint in the lineup when looking at the front of the lineup. The first case in the lineup will be labeled on the right end and the second case in the lineup will be labeled on the left end. The numbers on each end to be joined will match, as indicated (See Figure 1).

FIGURE 1: Case Label Information



The *first* case in a lineup (with the right side labeled “x.1”) has a packet attached to the shelving that contains touch-up paint. Every case in a lineup has a packet attached to the shelving that contains important information about the case and/or lineup and, if applicable, special instructions for installing ordered options.

Roll guards and vertical joining strip (V-splice) are shipped on top of the case. Shelves for the case are tie-wrapped and blocked into the individual cases. Other accessories like expansion bases are shipped in the case that require the parts.

Materials for joining cases—including caulk, joining bolts, splices, and end filler posts—are shipped in each case to be joined.

Location

These cases must not be installed in the direct rays of the sun or near a source of radiant heat. Be certain that the floor under the installation is of sufficient strength to prevent sagging. Uneven surfaces will result in reduced performance.

Cases must be set to allow a minimum 3" of space behind the back of the units. This will allow necessary air to circulate behind the display cases and prevent condensation. Higher humidity stores with minimal air circulation require at least a 4" gap. A minimum 2" gap is recommended between cases on end-to-end installations. All minimum spacing requirements may increase if seismic restraints are used. Refer to document 66-0180, Seismic Instructions, for details on installing seismic restraints.

Building soffits are not recommended for this display case.

PLANNING

Moving Cases

Various tools and equipment may be used to move cases, including, but not limited to, a forklift, a Johnson bar, a pallet jack, furniture rollers, casters, or a Rol-A-Lift. Be careful to avoid damaging the store flooring. Only certified forklift drivers should use forklifts to move the cases. The case should only be lifted off the floor as high as necessary for transport. The forklift should be driven slowly; avoid abrupt motions or bumps.

- Use the end frame to push/pull the case. For best results, push/pull lower on the end frame. **Do not push/pull on the mullions as this can cause the mullions to bend.**
- When using a Johnson bar, only contact the sheet metal of the bottom foamed panel. **Be careful not to pierce the sheet metal with the corner of the Johnson bar.**
- When using a pallet jack or furniture rollers, only place them under the floor foamed panels between the bases.
- Cases have steel protective support plates under the end panels (not under insulated dividers) to protect them from Johnson bar damage.

Make sure that a forklift with the proper fork dimensions is available. **Forks must be 48" long, 1 1/2" to 1 3/4" thick, and no more than 4" wide to fit the bases.** Refer to the table below for instructions.

CASE MODELS	INSTRUCTIONS
2CGMC30 & 2CGLC30	Forks must extend 26" to 30" under the case from either end
3CGMC30 & 3CGLC30	Forks must extend 39" to 43" under the case from either end
4CGMC30 & 4CGLC30	Forks must extend 44" to 47" under the case from either end
5CGMC30 & 5CGLC30	Forks must extend 44" to 47" under the case from either end

Leveling

Cases should be set level from right to left to allow complete drainage of defrost and condensate water. Since a level floor area is seldom available, the following steps will ensure a level installation. If your case uses seismic restraints, specific instructions for attaching seismic restraints are included in your document package. **Read and understand these instructions before assembling the lineup. View our seismic bracket installation instruction for more details.**

1. Measure off and mark on the floor the exact dimensions of the case lineup (**See Figure 2**). Refer to the fixture plan or floor plan.
2. Snap a chalk line at the locations for the front and back positions of the bases.
3. Mark locations of all joints, both front and back.
4. Using a laser level or transit, find the highest point along both base position lines. Using the high point as a reference, mark the difference directly on the floor to each base, both front and back (**See Figure 3**).

FIGURE 2: Measure and Mark Exact Case Outline






FIGURE 3: Mark Floor Level Difference




PLANNING

FIGURE 4: CGMC30 & CGLC30 Base Locations


Drawings are top views with bases shown under the case. The front of the case is toward the bottom of the page.
Case length does not include end panels (2 1/2" wide each).




2CGMC30 & 2CGLC30



3CGMC30 & 3CGLC30



4CGMC30 & 4CGLC30



5CGMC30 & 5CGLC30

PLANNING

- Place enough shims under each base to equal the highest point. Shims should not extend beyond the front case bases or they will interfere with installing trim. The shims should be oriented to sit under the front and rear bends of each base. Tape all shims in place (See Figure 5 and Figure 6).

FIGURE 5: Tape Shims on the Floor Under Each Base






FIGURE 6: Shims Under Bases




CAUTION!

SHIMS MUST BE PLACED UNDER THE FRONT AND REAR EDGES OF EACH BASE, SPANNING FRONT TO REAR, TO PREVENT THE BASE FROM WARPING/BUCKING



- To maintain even, consistent gaps and proper door operation, the case must be leveled front-to-back and side-to-side. Ensure that the case is set square to within 1/8" (See Figure 7). After the case is set, use at least a 48" level to ensure the case is level. Add additional shims as needed under specific bases.
- Place additional support shims under any bases with gaps taller than one shim. **Note: Total height of shims should be less than 3/4".**
- Remove the protective steel plates from under the end panels.**

FIGURE 7: Case Squareness



- Measure squareness from top right corner of the case to the bottom left corner of the case.
- Measure again from the top left corner of the case to the bottom right corner of the case.
- Measurements should be equal. Difference should be no more than 1/8".

Lineup Assembly

Zero Zone display cases have been designed for continuous display so that multiple cases may be joined together to create a lineup of any desired length. The lineup will be ready for assembly after removing the packaging material.

A case lineup must be properly aligned, which starts with properly leveling the case (See "Leveling" on page 9). It is crucial to use a laser level to measure the high points in the floor and properly shim each base location.

The bottom of the end panels are protected by steel support plates, which must be unbolted and removed before the lineup is set. There are bolts that go up through the support plates into the underside of the foamed floor.

A case must be prepared with Butyl caulk before setting the next case in the lineup. Case caulking instructions and caulk are shipped with every case (See Figure 11 on page 13).

PLANNING

Move the next case into position bump-tight and bolt it to the first case using the joining bolts that are provided (**See Figure 8**). Begin tightening the bolts at the top rear, working down the back of the case and up the front, making sure that the seams are flush. **Do not use the joining bolts to drag the display cases into their final position.** Alignment holes are located in the rear end frames near the joining holes; use a drift pin or screwdriver to ensure those holes are aligned. Please note that Guardian® cases have a weldnut in the rear center of the left end frame; this weldnut makes it possible to join the cases without removing the shelves and rear duct from the right case at the joint.

The vertical joining splice (V-splice) will be shipped with the roll guard. Install the V-splice at the joint between cases by snapping it onto the end mullions of the adjacent cases (**See Figure 9 and Figure 10**). The V-splice must be installed low enough to clear the door's top electrical connector and high enough to clear the door's torque adjuster.

An insulated divider is used to join 2 different case models or 2 different temperature cases. The divider is typically factory installed to one of the cases.

Between Guardian® cases: The insulated divider uses a thru-bolt design. The divider is attached to one of the cases using short bolts for shipping. After the cases are installed, remove the short bolts one at a time and install the longer joining bolts to bolt the cases together. **Do not use the joining bolts to drag the display cases into their final position.** Each joining bolt requires 2 hex nuts.

The interior case seams must be sealed using silicone sealant for NSF compliance (**See Figure 12 on page 14**). Do not allow Butyl caulk and silicone sealant to contact one another as this may affect adhesion or color of each.

FIGURE 8: Case Joining Hardware
Only showing end frames of cases




FIGURE 9: Vertical Joining Splice (V-splice, Top View)





FIGURE 10: Vertical Joining Splice (V-splice, Front View)




Note: Plexi divider is not shown in the above image.

PLANNING

Before joining the cases, remove all packaging material on the display case, including any spacer blocks inside the bases. Repeat caulking between each case in the lineup.

FIGURE 11: Case Joint Caulking (Butyl*)



*DO NOT APPLY BUTYL CAULK ON SEAFOOD OR BAKERY CASES. Butyl caulk never cures and emits vapors that affect seafood and bakery products. Recommended alternative caulk: Polyurethane-based (full curing, durable, moisture-activated) or silicone-based (full curing).

IT IS CRITICAL TO FOLLOW THIS PROCEDURE TO ENSURE CASES ARE PROPERLY SEALED.


SURFACES TO BE CAULKED MUST BE CLEAN, DRY, FREE OF TAPE/ADHESIVE, AND FREE OF FROST (ABOVE 40°F).

Note: Apply Butyl caulk to only one case—not both cases. The caulk will spread out when the cases are pushed together, and excessive caulk may squeeze out of the joint. Wipe away any caulk that squeezes out. Butyl caulk will not mix with silicone sealant (used for NSF sealing), which will affect adhesion of both.

Note: Increase bead size for irregular surfaces.

1. Apply 1/2" thick beads of Butyl caulk* along the ceiling, rear wall, bottom of the case, and the mullion where indicated by the dashed lines in the drawing.
2. Caulk must be continuous with no gaps. Always apply 2 beads where specified. Caulk must be applied around the polycarbonate divider and not onto the divider itself, if applicable.
3. After cases are joined and tightened, caulk the top and back exterior seams, if accessible, to ensure a tight seal.

FIGURE 12: NSF Compliance Sealing (Silicone)



THIS PROCEDURE MUST BE FOLLOWED FOR NSF COMPLIANCE.

SURFACES TO BE SEALED MUST BE CLEAN, DRY, FREE OF BUTYL CAULK, AND FREE OF FROST (ABOVE 40°F).

Note: Cases must be properly caulked and joined before NSF sealing. Wipe away any Butyl caulk that squeezes out of the case joint. Butyl caulk and silicone sealant will not mix, which affects the adhesion of both. See Figure 11 on page 13.

1. Apply silicone-based sealant in small, continuous beads where indicated by the dotted lines in the drawing. Do not thin or feather, as that will affect adhesion.
2. **Incomplete or improperly applied seals can allow air infiltration into the display case, leading to frost accumulation in low-temperature units. Both low- and medium-temperature cases are susceptible to condensation, which may result in water pooling at the base of the display case.** Sealant must be added between cases at case joints, between a case and an end panel, and between all access holes and cut-outs in the case end frame.

INSTALLATION & OPERATION

Packaged Refrigeration Unit (PRU) Installation

- WARNING!** A MINIMUM OF TWO PEOPLE ARE REQUIRED FOR PRU INSTALLATION OR REMOVAL.
- CAUTION!** DO NOT STAND ON TOP OF A GUARDIAN® MERCHANDISER. THE TOP OF THE CASE IS NOT DESIGNED TO SUPPORT THE WEIGHT OF A PERSON.
- CAUTION!** VERIFY THAT THE CORRECT SUPPLY VOLTAGE FROM BUILDING POWER IS PRESENT BEFORE ENERGIZING THE EQUIPMENT. THE LOW-TEMPERATURE DISPLAY CASE REQUIRES 208 VAC, AND THE MEDIUM TEMPERATURE DISPLAY CASE REQUIRES 115 VAC. VERIFY THAT ALL PHASES MEASURE 115 VAC AND ENSURE THAT NO PHASE IS CONNECTED TO THE HIGH LEG OF THE BUILDING'S ELECTRICAL SERVICE. MEASURE ALL LEGS TO NEUTRAL.
- CAUTION!** DO NOT REMOVE THE EVAPORATOR COVER BOLTS. AMBIENT AIR WILL INFILTRATE THE ENCLOSURE AND CAUSE FROST AND ICE FORMATION IF THE EVAPORATOR COVER'S SEAL IS NOT PROPERLY RETURNED AFTER SERVICING.

Note: The following procedure will name specific tasks for technician one and technician two. Technician one will be positioned on the left side of the PRU when facing the front of the PRU. Technician two will be positioned to the right side of the PRU when facing the front of the PRU. The PRU weighs 85 pounds.

Note: Ensure the PRU being placed matches the cooler or freezer.

1. Remove the packaging from the openings on top of the display case.
 2. Place the PRU in front of the Display case. The insulated enclosure shall be oriented toward the rear of the display case.
 3. Technician one and technician two will lift their respective side of the PRU. Place the rear of the PRU on top of the display case (**Figure 16**).
- CAUTION!** DO NOT PUSH THE PRU COMPLETELY ONTO THE DISPLAY CASE. PUSHING THE PRU COMPLETELY ON TOP OF THE DISPLAY CASE CAN RISK THE PRU FALLING BEHIND THE DISPLAY CASE AND WILL MAKE ALIGNMENT MORE DIFFICULT.
4. Both technician one and technician two will slide the PRU towards the rear of the display case until a maximum of 6 inches of the PRU overhangs the front of the display case (**Figure 13**).
 5. Technician one will maneuver toward the front of the PRU while keeping at least one hand on the unit at all times.
 6. Technician two will move to the top of a step ladder placed in front of the display case.
 7. Technician two will orient the PRU to align the mounting holes as technician one pushes the PRU toward the rear of the display case (**Figure 14**).

FIGURE 13: Lifting the PRU



FIGURE 14: Aligning the PRU



INSTALLATION & OPERATION

Note: It is recommended to use an 18" socket extension with magnetic retention to tighten the center-rear mounting bolt. Always use a ladder that is appropriate for the task and complies with relevant safety standards and regulations.

CAUTION! IF USING POWER TOOLS, ENSURE THEY ARE ON THE LOWEST TORQUE SETTING TO AVOID STRIPPING SCREWS AND CRACKING THE PRU MOUNTING PLATE.

8. Secure the PRU to the display case using the 7 provided bolts. Torque in a cross pattern to 50 in-lbs. (See Figure 16).
9. Connect the PRU power cord to the receptacle on the rear of the power distribution box or upper electrical box.
10. Connect the display case to its power source and apply power.

Controller Installation

Note: The controller is mounted in the shipping position on the PRU.

1. Remove the two screws attaching the controller to the PRU.
2. Move the controller forward to be flush with the front of the display case and aligned with the forward mounting holes. Mount the controller in its operational position using the two mounting screws removed in step 1 (Figure 15).

Shroud Installation

Note: The controller must be installed before the shrouds.

Note: The shrouds must be installed on the display case before operation.

Note: The light switch is attached to the end of the wiring harness.

1. Detach the light switch from the end of the harness.
2. The screws that hold the upper raceway cover will be used to hold the front shroud. Loosen the screws without removing them (See Figure 17 on page 17 and See Figure 18 on page 17).
3. Slide the front shroud under those screws and tighten.
4. See the table for angle bracket quantities. Install the angle brackets to support the front shroud. Mount the angle brackets to the holes on the top flange of the shroud.
5. Screw the angle brackets to the top of the case. Use a level at each angle bracket location to ensure that the shroud is upright, and not tilting forward or backward.
6. Place the rear shroud on top of the display case.
7. Position the side shrouds perpendicular to the front and rear shrouds, on top of each end panel.
8. Screw the side shrouds to the front and rear shrouds to ensure a tight fit.
9. Install 1 angle bracket to support each side shroud. Mount the angle bracket to the holes on the top flange of the shroud, and screw the angle bracket to the top of the case. Use a level to ensure that the shroud is plumb.
10. Feed the wires for the light switch through the cutout in the shrouds.

Note: The orientation of the switch will not affect light function.

11. Reattach the harness to the switch.
12. Install the heat deflectors between the PRUs on the PRU base, ensuring the wiring egress is oriented towards the rear of the display case (See Figure 19 on page 17).

FIGURE 16: PRU Torque Order





FIGURE 15: Controller Mounting

Viewed from Top of Case
Front of case Lower in Image



Number of Angle Brackets for Front Shrouds

CASE SIZE	ANGLE BRACKETS
2-Door	1 Brackets
3-Door	1 Brackets
4-Door	2 Brackets
5-Door	3 Brackets

INSTALLATION & OPERATION

FIGURE 17: Upper Raceway Cover Screws





FIGURE 18: Shroud Support Brackets and Heat Deflectors



Nesting Base Installation

The Nesting Bases are shipped loose with the display case and are not factory-installed. A forklift is the preferred method for lifting the display case to install the nesting bases.

Acceptable alternatives to forklift installation are:

- Johnson Bar
- Rol-a-Lift
- Pallet jack

INSTALLATION PROCEDURE

13. Ensure the case is unpowered and clear of all packaging material.
14. Lift the display case using a forklift or acceptable alternative.
15. Slide the nesting base onto the display case base until the tabs are fully seated in the mounting slot (See Figure 20).
16. Lower the display case.

FIGURE 19: Heat Deflector Installation





FIGURE 20: Nesting Bases



INSTALLATION & OPERATION

Shroud Splice Installation

The Guardian® Merchandiser is able to be joined in a lineup with different display case models. The instructions below are for a seamless shroud installation between the case models.

1. Join the display cases by following the steps outlined in the Installation and Operation Manual for the Guardian® Merchandiser and the case model to be joined.
2. Place the End Panel Splice over the joint between the Guardian® and the adjacent display case. Secure the End Panel Splice with 2 screws (See Figure 21).
3. Place the Kickplate Close-Off at the end of the kickplate between the Guardian® Merchandiser and the adjacent display case, positioned behind the End Panel Splice. Secure the Kickplate Close-Off with 2 screws (See Figure 22).
4. Install the front shrouds on the Guardian® Merchandiser and adjacent display case according to the Installation and Operation Manuals.
5. Attach the Splice Shroud to the front shrouds of the Guardian® Merchandiser and adjacent display case using 4 screws (See Figure 23).

FIGURE 21: End Panel Splice






FIGURE 22: Kickplate Close-Off



**FIGURE 23: Shroud Splice
View from Top Rear**



INSTALLATION & OPERATION


Roll Guard

Each case is shipped with a front roll guard. Cases with end panels are shipped with 1 side roll guard per end panel.

Note: Front and side roll guard are attached to the case bases using Magnets. (See Figure 24).

Note: Roll guards will ship with the display case.

1. Position side roll guard.
2. Position front roll guard



CoolView® Doors

DOOR HANDLES

CoolView® Envision® doors use a Classic™ door handle. These are attached to the door frame by screws.

HOLD-OPEN BRACKET

CoolView® doors are self closing, and closing tension increases as the door opens wider. The hold-open bracket keeps the door open when engaged, which is useful for stocking shelves or case maintenance. To engage the hold-open bracket, open the door to at least 90° until it clicks. Closing the door to about 80° will release tension on the door, and it will self close again.

DOOR GASKET

Each single-swing door has a full perimeter gasket mounted to the edge of the door.

INSTALLATION & OPERATION

Packaged Refrigeration Unit (PRU) Removal



WARNING!

A MINIMUM OF TWO PEOPLE ARE REQUIRED FOR PRU INSTALLATION OR REMOVAL.



CAUTION!

DO NOT STAND ON TOP OF A GUARDIAN® MERCHANDISER. THE TOP OF THE CASE IS NOT DESIGNED TO SUPPORT THE WEIGHT OF A PERSON.

Note: The following procedure will name specific tasks for technician one and technician two. Technician one will be positioned on the left side of the PRU when facing the front of the PRU. Technician two will be positioned to the right side of the PRU when facing the front of the PRU.

1. Disconnect the power connector from the receptical.

Note: Using an 18" socket extension with magnetic retention is recommended to reach the center-rear mounting bolt.

2. Technician one will remain on the ground while technician two removes the 7 mounting bolts from the PRU while standing on a step ladder placed in front of the display case (See Figure 14 on page 15).
3. Technician two will lift the PRU to break any seal with the top of the display case.
4. Technician two will slide the PRU towards the front of the display case until the PRU overhangs the front of the display case by a maximum of 6 inches. Technician one will stabilize the PRU from the ground.
5. Technician two will descend the step ladder, then remove the step ladder from in front of the display case.
6. Technician one will move toward the left side of the display case while keeping at least one hand on the PRU at all times. Technician two will take their position to the right of the PRU.
7. Both technician one and technician two will slide the PRU completely off the display case. Place the PRU on a mobile cart or someplace debris will not enter the fan outlet of the PRU.
8. Cover the fan openings on the display case with cardboard to prevent debris from entering the display case.

INSTALLATION & OPERATION

ADJUSTING DOOR SAG/SAWTOOTH

Door sag/sawtooth is when the handle side of the door is either higher or lower than the adjacent door. To fix door sag on Guardian® cases, the torque adjuster must be moved by turning the sag adjustment screw.

Note: Cases requiring excessive adjustment may not be level. See Figure 7 on page 11.

1. Open the door to gain access to the sag adjustment screw (**See Figure 25**) on the bottom of the hinge side of the door.
2. Use a flathead screwdriver to turn the sag adjustment screw. Do not use power tools; a screwdriver allows for more control.
3. To lower the handle side of the door, turn screw clockwise. The torque adjuster should move away from you as you turn the screw.
4. To raise the handle side of the door, turn screw counter-clockwise. The torque adjuster should move toward you as you turn the screw.
5. Turn the sag adjustment screw until the door is level with the adjacent door.

FIGURE 25: Sag Adjustment Screw



TORQUE ADJUSTER / ADJUSTING DOOR TENSION

The torque adjuster automatically closes the door. It is located on the bottom of the hinge side of the door. The torque rod inside the door sets into the torque adjuster, which transfers the closing tension to the torque rod. This means that the torque rod must be aligned with the torque adjuster when installing a door. An adjustment screw on the front can be used to increase or decrease tension.

1. Open the door to observe current door tension. A properly tensioned door will close itself gently and not swing open.
2. Use a flathead screwdriver to turn the door tension screw (**See Figure 26**). **Do not use power tools; a screwdriver allows for more control.**
3. To increase tension, hold the door open 2" and turn the screw counter-clockwise until the door begins to close. Once it closes, increase tension by 2 more full turns.
4. To decrease tension, turn the screw clockwise.

FIGURE 26: Door Tension Screw



The torque adjuster is secured to a bracket that is attached to the display case.

REMOVING A DOOR

1. Turn the door tension screw clockwise until the door does not close on its own (**Figure 26**). This removes tension between the door and torque adjuster so the door can be removed.
2. Disconnect the hold-open bracket from the top of the door (**See Figure 27**).
3. Use a needle-nose pliers to pinch the hinge pin while closing the door. This will disconnect the door from the case (**See Figure 28 on page 22**). **Note: The door is heavy. Be prepared to catch the weight of the door.**
4. Lift the door clear of the torque adjuster and set it down carefully. **Note: For safety, lift the door by the rails; do not lift by the handle.**

FIGURE 27: Locate the Hold-Open Bracket



INSTALLATION & OPERATION

FIGURE 28: Use a Wedge & Pinch Hinge Pin



FIGURE 32: Push Door & Hinge Pin into Place



INSTALLING A DOOR

1. Lift the door and set it into the torque adjuster. Swivel the door back and forth until you can feel that the door has dropped into the torque adjuster. **Note: The door is heavy. For safety, lift the door by the rails; do not lift by the handle.**
2. Carefully open the door until it is perpendicular to the case, align the hinge pin, and then push the top of the door so the hinge pin clicks into place (See Figure 32). **Note: Test whether the door is held securely by the hinge pin by pulling down on the door.**
3. Attach the hold-open bracket between the top of the door and the top of the case (See Figure 27 on page 21).
4. Turn the door tension screw counter-clockwise until the door gently closes itself (See Figure 26 on page 21). Check for sag/sawtoothing.

REVERSING DOOR SWING

1. Remove the door from the display case. See "Removing a Door" on page 21 for a detailed description. **Note: The door is heavy. For safety, lift the door by the rails; do not lift by the handle.**
2. Lift the door clear of the torque adjuster and lean it on its side, handle side down. This makes it easier to access the wiring cover on the hinge side of the door.
3. The wires to the hinge pin must be disconnected. Remove the wiring cover, disconnect the ground screw, and then pull the wires out of the door (See Figure 29). Pry the hinge pin out from the top of the door and tug on it to identify which wires need to be disconnected (See Figure 30). Disconnect the bullet connectors and pull the hinge pin out.
4. Pry the torque rod from the bottom of the door using a screwdriver (See Figure 31).
5. Remove the hold-open bracket from the door.

FIGURE 29: Hinge Pin Wiring





FIGURE 30: Remove Hinge Pin



FIGURE 31: Remove Torque Rod



INSTALLATION & OPERATION

- Reinstall the hinge pin, torque rod, and hold-open bracket on the opposite ends of the door. For the hinge pin, after feeding the wires through the door and reconnecting them, it may be easiest to bundle the wires into 2 "ponytails" to fit them inside the door (**See Figure 29 on page 22**).
- There are two hinge locations per door opening (**See Figure 33 and Figure 34**). Remove the raceway cover to access the parts that must be switched to the opposite side of the door opening.
- Disconnect the terminal from the wire harness and remove the terminal from the raceway. Unscrew the gib and slide it to the side to remove. Swap the terminal and the gib to the opposite sides and reconnect the terminal to the wire harness. Swap the hole cover.

FIGURE 33: Left Hinge Location





FIGURE 34: Right Hinge Location



- Remove the hold-open fastener using a hex wrench to hold the bottom stationary and remove the nut on top. Remove the finned fastener (tree-shaped plug) on the opposite side. Swap the hold-open fastener and the finned fastener.
- To unlock the torque adjuster from the case, turn the locking screw that was under the torque rod by 1/16 turn (**See Figure 35**). Remove the torque adjuster. Pry up the torque adjuster plug on the opposite side (**See Figure 36**). Swap the plug and torque adjuster.

FIGURE 35: Torque Adjuster Locking Screw




FIGURE 36: Torque Adjuster Plug



- Install the reversed door. **See "Installing a Door" on page 22** for a detailed description. **Note: The door is heavy. For safety, lift the door by the rails; do not lift by the handle.**


LIGHT REPLACEMENT

- Remove the Light Electrical Covers from the display case (**See Figure 37**).
- The electrical connectors are located under the internal display case sill covers. Disconnect the lights from the harness (**See Figure 38**).

INSTALLATION & OPERATION

3. The lights are attached to the mullions by two screws: one at the top and one at the bottom. Remove these screws (See Figure 39).
4. Remove the light from the display case.
5. Place the replacement light on the rear of the mullion connector side facing down. Secure the replacement light using the two screws from the previous light (See Figure 39).
6. Connect the replacement light's electrical plug to display case power (See Figure 38).
7. Reinstall the electrical cover (See Figure 37).

FIGURE 37: Light Electrical Cover Locations



Shelves & Stocking Product

On 2 to 5-door cases, tilt the shelf sideways and bring it through the door. Level the shelf inside the case and tilt the back of the shelf down so the shelf tabs fit into the slots in the shelf standards. Lower the front of the shelf until the shelf is held securely by the standards. To unassemble a shelf, insert a putty knife between the side of the shelf and the shelf bracket. Pry the pieces apart to disengage the bracket.

FIGURE 38: Light Electrical Connector
Inside view from rear of display case.





FIGURE 39: Light Mounting Screw
Inside view from rear of display case.



Shelf location may be adjusted in 1" vertical increments in any position for best display advantage. Make sure the shelf brackets are securely seated before placing any product on the shelf. The standard shelves may be tilted down at a 10° angle. The case may be stocked with product after it has operated at least 24 hours with correct case temperature and proper control operation. Product should not extend beyond the front of the shelves or bottom wire rack. **Do not exceed shelf load capacity (See Figure 40). Do not stand on the case when stocking or adjusting shelves.**

Shelves may accommodate price tag molding and product stops. Slide the product stop into the price tag molding and push it down to the bottom of the channel. The channel of the price tag molding may need to be pried open with a screwdriver, but the product stop should slide in easily once started.

FIGURE 40: Shelf Load Capacities

SHELF TYPE	WIDTH	DEPTH	BRACKET TYPE	LOAD CAPACITY (LBS.)
Solid Shelf	30"	24"	2-Position (0°/10°)	175/75
Bottom Wire Rack	30"	23.55"	0°	175

REFRIGERATION

Operation Set Points

Refer to the case spec sheet for btu/h requirements and electrical requirements. See Figure 41 for control setpoints.

FIGURE 41: Control Setpoints

SETTING	MEDIUM-TEMPERATURE	LOW-TEMPERATURE
Control Setpoint	36°F	-6°F

Defrost

Periodic defrosting to keep the evaporator coil free of frost is accomplished by a time clock used in conjunction with an hot gas defrost. Defrosts occur at regular intervals throughout the day based on the defrost schedule. Defrosts will terminate either by reaching the termination temperature or maximum defrost time (See Figure 42). If one of the evaporator enclosures of the PRUs is open for extended service, the other PRUs may need a manual defrost.

FIGURE 42: Defrost Settings

SETTING	MEDIUM-TEMPERATURE	LOW-TEMPERATURE
Defrost Type	Hot Gas	Hot Gas
Frequency	2 Per Day	6 Per Day
Duration	15 Minutes	20 Minutes
Temperature Termination Set Point*	45°F	65°F

*The termination set point is the return air temperature.

HOT GAS DEFROST

The timer starts the hot gas defrost cycle by energizing a solenoid, opening the hot gas bypass valve. The hot gas leaves the compressor discharge to pass through the serpentine loop before entering the evaporator coil through the liquid line. It flows through the coil in the same direction as the refrigerant during a refrigeration cycle. The defrost cycles are a time differential, not a specific time of day. The PRUs may enter defrost cycles at different times.

Press and hold the Defrost key for 2 seconds to start a manual hot gas defrost cycle. The controller displays "dEF," and the melting snowflake icon illuminates. The icon flashes during drip time. After drip time ends, the icon turns off, the display shows the setpoint temperature for 30 minutes, and the fan icon flashes until the fan delay expires.

For freezers, evaporator fans operate when the condensing unit is running and probe P2 is below 30°F, except during a hot gas defrost cycle when fans are off. After defrost, the system remains idle for a 6-minute drip time, then refrigeration restarts. The evaporator fans resume 2 minutes later.

For coolers, evaporator fans run continuously when probe P2 is below 70°F, except during hot gas defrost when fans are off. After defrost, there is a 2-minute drip time, and fans restart immediately.

Hot gas defrost termination sensors are located on the evaporator coil inside of the PRU.

Air Sensors & Case Thermometers

- Return air sensor is located in the PRU return air stream.
- Hot gas defrost termination sensors are located in the evaporator coil inside of the PRU.
- An NSF thermometer is shipped loose and should be installed in the warmest product location as required by NSF. Specific field installation instructions are packaged with the NSF thermometer.
- During a high-temperature alarm, the case controller displays "HA" and sounds an audible alarm.

REFRIGERATION

XR60CH Controller

The Guardian PRU is equipped with an XR60H controller (**See Figure 43**). The controller allows the operator to:

- Adjust the temperature setpoint
- Initiate a manual defrost
- Lock or unlock the keypad
- Power the unit on or off

CONTROLLER STATUS ICONS

The XR60CH controller uses the following icons to indicate operating status:

- Solid Snowflake: Cooling mode
- Blinking Snowflake: Anti-short cycle enabled
- Solid Melting Snowflake: Defrost mode
- Blinking Melting Snowflake: Drip mode
- Solid Fan: Fans enabled
- Blinking Fan: Fan delay after defrost enabled

UNLOCKING THE KEYPAD

1. Long press the UP and DOWN arrow keys simultaneously for more than 3 seconds.
2. The display will show "POn", indicating the keypad is unlocked.

LOCKING THE KEYPAD

1. Long press the UP and DOWN arrow keys simultaneously for more than 3 seconds.
2. The display will show "POF", indicating the keypad is locked.
 - a. "POF" will display if any key is pressed while the controller is locked.

CHANGING THE TEMPERATURE SETPOINT

1. Long press the SET key for more than 2 seconds.
 - a. The current setpoint value will be displayed and the °F icon will blink.
2. Press the UP or DOWN arrow key to adjust the setpoint to the desired temperature.

POWER ON/OFF THE PRU

1. Press the Sun/Moon key
 - a. Controller will display "OFF" when power is cycled off.
 - b. The temperature will be displayed when power is cycled on.

FIGURE 43: XR60CH Controller



FIGURE 44: Guardian Merchandiser Setpoints

GUARDIAN® MERCHANDISER SETPOINTS		
APPLICATION	LOW-TEMPERATURE	MEDIUM-TEMPERATURE
Factory Setpoint	-6°F	36°F
Setpoint Range	-15°F to +10°F	32°F to 41°F
Ice Cream	-10°F	N/A
Ice Merchandiser	0°F	N/A
Fresh Meat	N/A	32°F

REFRIGERATION

Anti-Sweat Heaters

All mullions are equipped with anti-sweat heaters. They are located behind the front metal strike plate. Remove the front fasteners on the mullion, and then remove the front strike plate to access the heater.

The low-temperature case glass has an anti-sweat heater. It is located under the front metal strike plate below the door opening.

Contact the Zero Zone Service Department for questions about servicing anti-sweat heaters.

Wiring Information




CAUTION!

VERIFY THAT THE CORRECT SUPPLY VOLTAGE FROM BUILDING POWER IS PRESENT BEFORE ENERGIZING THE EQUIPMENT. THE LOW-TEMPERATURE DISPLAY CASE REQUIRES 208 VAC, AND THE MEDIUM TEMPERATURE DISPLAY CASE REQUIRES 115 VAC. VERIFY THAT ALL PHASES MEASURE 115 VAC AND ENSURE THAT NO PHASE IS CONNECTED TO THE HIGH LEG OF THE BUILDING'S ELECTRICAL SERVICE. MEASURE ALL LEGS TO NEUTRAL.

The Electrical Contractor is to provide a wiring disconnect, unless present on upper electrical box, between the panel breaker and case for each AC line (per National Electric Code). To prevent a disconnect arc, ensure the breaker is open before unplugging the case.

FIGURE 45: Electrical Power Distribution Assembly Wiring



REFRIGERATION

ELECTRICAL POWER DISTRIBUTION ASSEMBLY WIRING

The electrical power distribution assembly wiring diagram (Figure 45) is shown with three receptacles. The number of receptacles in this box will match the number of PRUs on the case.

TERMINAL BLOCK CONNECTIONS

FIGURE 46: Terminal Block Connections Single AC Line





FIGURE 47: Terminal Block Connections Multiple AC Line



Wiring Labels

FIGURE 48: CGLC Wiring Label





FIGURE 49: CGMC Wiring Label



Other Information

See the Packaged Refrigeration Unit (PRU) manufacturer's documentation for all other refrigeration information.

MAINTENANCE

Cleaning

Although each Zero Zone display case is thoroughly cleaned before shipping, the cases should be thoroughly cleaned again before start-up and routinely thereafter to maintain a clean appearance. With just a few minutes of cleaning each week, the case will remain in top condition.

Note: *Reference the PRU manufacturer's manual for cleaning the PRU.*



CAUTION!

ONLY USE AMMONIA FREE GLASS CLEANER.



CAUTION!

DO NOT USE LIQUID CHEMICALS TO CLEAN THE DISPLAY CASE OR COMPONENTS.

1. Do not use high-pressure water or steam to clean the interior or components.
2. Clean the case interior with a mild detergent and warm water. Do not use abrasive cleaners.
3. Blow out the condenser coil using nitrogen or compressed air. Verify all connections and screws are secure.
4. Clean the condensate collection twice annually and after each condenser coil cleaning.
5. Clean all glass doors using glass cleaner. Cleaning interior glass reduces fogging and increases visibility.

UNDER CASE FLOOR CLEANING (NSF)

The floor under your Zero Zone display case can be cleaned by following these steps:

1. Remove the magnetic roll guard from the case.
2. With the roll guard removed, remove debris from the floor.
3. Vacuum under the case to remove any dirt, debris, and dust build-up.
4. Mop under the unit using non-abrasive floor cleaner and warm water.
5. When finished mopping, squeegee any remaining water under the unit to speed up the drying process. Replace the roll guard when the floor has dried.

APPENDIX

Removal and Replacement of the Evaporator Cover

FIGURE 50: Evaporator Cover Bolt Torque Pattern



EVAPORATOR COVER REMOVAL

CAUTION! CONTACT ZERO ZONE TECHNICAL SUPPORT BEFORE REMOVING THE EVAPORATOR COVER FOR TROUBLESHOOTING GUIDANCE. AMBIENT AIR WILL INFILTRATE THE ENCLOSURE AND CAUSE FROST AND ICE FORMATION IF THE EVAPORATOR COVER'S SEAL IS NOT PROPERLY RETURNED AFTER SERVICING.

CAUTION! DO NOT USE POWER TOOLS TO REMOVE OR INSTALL BOLTS FROM THE EVAPORATOR COVER.

CAUTION! THE NYLON BOLTS MAY BE DIFFICULT TO REMOVE DUE TO ICE BUILDUP. BREAK TORQUE USING PLIERS.

1. Remove the bolts from the evaporator cover in the reverse sequence as shown in **Figure 50**. Remove screw 4 first, then 3, then 2 and finally 1.

Note: The foam cover forms a compression seal. It may require gentle rocking to disengage.

2. Remove the foam cover.

EVAPORATOR COVER INSTALLATION

CAUTION! ENSURE THE ENCLOSURE GASKET IS PROPERLY SEATED BEFORE INSTALLING THE EVAPORATOR COVER. THE SEAL MUST BE FREE OF KINKS, RIPS, OR TEARS. PERMAGUM MUST BE USED TO SEAL THE REFRIGERATION PIPING AND ELECTRICAL WIRING EGRESS.

CAUTION! DO NOT USE POWER TOOLS TO REMOVE OR INSTALL BOLTS FROM THE EVAPORATOR COVER.

1. Engage the threads of all the evaporator cover screws one to two turns by hand.

CAUTION! DO NOT OVER TORQUE THE SCREWS. EXCESSIVE TORQUE MAY DAMAGE COMPONENTS OR COMPROMISE SYSTEM INTEGRITY.

2. Tighten screw 1, then torque the screws 2, then 3 and finally 4 to 20-30 in-lbs. Re-tighten screw 1 to ensure a proper seal (**See Figure 50**).

APPENDIX



Reach-In Display Case

Current Model Nomenclature

Current Model IDs
66-0139-D | 3/4/2025

3RHMC30TBB-D

Number of Doors

1, 2, 3, 4, 5, 6

Type of Case

R = Reach-In/Remote
C = Self Contained

Style of Case

V = Crystal™
H = Highlight™
G = Guardian™

Operating Temperature

M = Medium Temp
L = Low Temp

Case Shelving

C = Cantilever

Door Width

24"
30"

Applications

-B = Beverage
-D = Dairy/Deli
-F = Floral
-M = Meat
-P = Produce

Special

BB = Back-to-Back
BC = Bottom Coil
D = Deep
DT = Dual Temp
IM = Ice Merchandiser

Case Height

T = Tall

[Click for MULTI-DECK REACH-IN Model Nomenclature \(66-0138\)](#)

[Click for LEGACY Model Nomenclature \(66-0140\)](#)



For other technical support, please refer to
the Technical Resources page at:

WWW.ZERO-ZONE.COM

or contact the Zero Zone Service Department at:

800-247-4496

All specifications subject to change without notice.

